


TV STAND Manual

Model no.:AL-55



Fit screen size:17"-55"(most)

Max loading weight:20kgs


VESA:200x200,400x400mm




Accessories list:



Bottom plate with wheels(1pc)




Pipe(x1pc)



Pipe(x1pc)





adaptor(x4pcs)




vesa plate(1pc)

Step-1:Install the pipe to the bottom plate.





Loosen the pre-assembled bolts




Tighten


Step-2:Install upper pipe to lower pipe.



Loosen the pre-assembled bolts




Insert the upper pole




Tighten


Step-3: Attach adaptors to VESA plate.



Step-4: Chose the suitable height you want.



Step-5: Install TV to the stand.



Step-6: Switch screen Horizontally and Vertically.

